



***James Webb Space Telescope (JWST)
Integrated Science Instrument Module (ISIM)
Cryogenic Component Test Facility***

***Presented by
Edward A. Packard***

***23rd Space Simulation Conference
November 8-11, 2004***



Presentation Overview



- **JWST / ISIM Overview**
- **ISIM Thermal Verification Requirements**
 - **Emittance Test Objectives**
- **Cryochamber Design Requirements**
- **Cryochamber Construction**
- **Emittance Test Sample Selection and Configuration**
- **Error Sources and Error Mitigation**
- **Cryochamber Operation**
- **Cryochamber and Emittance Sample Test Results**
- **Future Considerations**




JWST Overview



- **Large infrared observatory positioned at L2**
- **Proposed launch date: August 2011**
- **Mission goals:**
 - **Understand the birth and formation of stars**
 - **Determine how planetary systems form**
 - **Explain galaxy formation**
 - **Determine the shape of the universe**
 - **Provide a better understanding of the intriguing dark matter problem**



JWST Conceptual Illustration






ISIM & Enclosure on JWST




Integrated Science Instrument Module (ISIM)

- Near Infrared Camera (NIRCam)
- Near Infrared Spectrograph (NIRSpec)
- Mid Infrared Instrument (MIRI)
- Fine Guidance Sensors (FGS)





ISIM Thermal Verification Flow






TIS5 Test Objective



- To determine the emittance of candidate thermal control coatings for the JWST/ISIM Instrument Assembly from 30K to 293K
- To minimize associated error bars in determining emittance values (goal <5%) at 30K





First Analytical Method



• Transient Cool-Down

$$\left(mC_p dT / dt \right)_{sample} = \sigma (A\varepsilon)_{sample} \left(T_{sample}^4 - T_{LHeShroud}^4 \right) + Q_{loss}$$

where $\left(mC_p \right)_{sample} = \sum \left(mC_p \right)_{substrate+coating+sensors}$

and $T = f(t)$

m	mass	measured pre test
C_p	specific heat capacity	theoretical*
T	temperature	measured test data
t	time	measured test data
σ	Stephan-Boltzmann constant	= $5.67 \times 10^{-8} \text{ W/m}^2/\text{K}^4$
A	sample radiating area	measured pre test
Q_{loss}	lead wire+residual gas loss	calculated
ε	emittance	determined from above equation



Second Analytical Method




• Steady State Warm-Up

$$Q_{heater} = \sigma (A\varepsilon)_{sample} \left(T_{sample}^4 - T_{LheShroud}^4 \right) + Q_{loss}$$

T	temperature	measured test data
σ	Stephan-Boltzmann constant	= $5.67 \times 10^{-8} \text{ W/m}^2/\text{K}^4$
A	sample radiating area	measured pre test
Q_{loss}	lead wire+residual gas loss	calculated
Q_{heater}	heater power	measured test data
ε	emittance	determined from above equation



Test Profile – Overview Timeline





Cryochamber Design Requirements



- **Relatively large: $A_{\infty} \gg A_s$ (chamber area \gg sample area) and at least 3'x3'x3' (1m^3)**
- **Cool-down from 295K to $< 7\text{K}$ in < 8 hours**
- **Thermal gradient $< 1\text{K}$**
- **Thermal stability $< 0.1\text{K/hr}$**
- **Chamber pressure $< 1 \times 10^{-7}$ Torr**
- **Cheap (to build and operate)**



Cryochamber on Facility 239 Payload Cart





Cryochamber Design Overview




- **Volume: 6'L x 4'W x 5'H (1.9m x 1.2m x 1.5m)**
- **Utilized 11 existing cryopanel**
 - (5) 76" x 29"
 - (2) 76" x 23"
 - (2) 61.5" x 29"
 - (2) 54" x 23"
- **Cryopanel** painted with Aeroglaze Z307
- **Supported** by an “exoskeleton” frame
- **Plumbed** in four parallel circuits
- **Covered** with single-layer, two-sided VDA



Cryochamber Thermal Isolation



- Cryopanel supported by G-10 isolators with $L/W=3.6$



- Three mil double sided VDA over gaps between panels
- Three mil double sided VDA over all panels
- Four-layer MLI wrapped around all tubing

Calculated conduction and radiation heat loss = 10.7W



Cryochamber Instrumentation




- **Temperature**


- (15) LakeShore DT-470-CU-13 standard curve silicon diodes used for panel and tube monitoring to LHe temperatures
 - $\pm 1\text{K}$ accuracy
- (20) Type T thermocouples used for fixture and tube monitoring down to LN_2 temperatures

- **Pressure**

- NIST traceable calibrated Granville Phillips Stabil-Ion Gauge on Chamber
 - $\pm 4\%$ accuracy per decade from 1×10^{-2} to 1×10^{-9} Torr









Test Samples



- **Sample selection**

- (2) Bare 8" x 8" x 0.024" (8 ply) M55J-954-6 Composite
- (2) Black Kapton (2 mil) on 8" x 8" x 0.020" A1100 Aluminum Substrate
- (2) Z306 Black Paint on 8" x 8" x 0.020" A1100 Aluminum Substrate

- **One transient (without heaters) and one steady state (with heaters) sample for each sample type**



Test Sample Description



- **Steady State Sample Heaters**
 - (4) 3" x 3" Minco HK5174R82.3I12B
 - 82.3 Ohms each wired in series
- **Temperature Sensors**
 - (2) LakeShore DT-470-SD-13 silicon diodes per sample
 - Calibrated from 4K-100K within at least +/-50mK
- **Wiring**
 - Heater to heater: 40AWG Cu; PTFE insulation; Aluminum tape overlay
 - Power leads: 30 AWG Manganin; Formvar insulation; VDA overcoat
 - Voltage leads: 36 AWG Manganin; Formvar insulation; VDA overcoat
 - Silicon diodes: 36 AWG Phosphor bronze; 2 twisted pairs; Formvar insulation



Steady State Test Sample Configuration




-Thermal control coating applied over heaters (except M55J)

-For M55J sample heaters covered with Aluminum tape.

- Heaters for steady state samples only.

-Al tape over SD sensors & heater leads.

-Sensor/heater lead wires not shown






Test Sample Configuration



-Alternating transient / steady state samples


-Kevlar suspension not shown






Thermal Desktop™ Model




Test Sample Support Frame





- Black anodized
- Conductively coupled to He shroud
- Tension springs to attach Kevlar to frame







Test Sample Control & Measurement



System Accuracy
Power: $<0.001\text{mW}$
Temperature: $\pm 50\text{mK}$



Emissivity Determination



- **Thermal Balance Equations**

- Transient

$$Q_c = \left(m C_p dT / dt \right)_{sample} = Q_{rad} + Q_{gas} + Q_{wire}$$

- Steady State

$$Q_{htr} = Q_{rad} + Q_{gas} + Q_{wire}$$

where:

Q_c	sample internal energy rate of change
m	mass
C_p	Specific heat capacity
T	temperature
t	time
Q_{rad}	radiation to He shroud
Q_{gas}	residual gas conduction to He shroud
Q_{wire}	heater / sensor lead wire loss
Q_{htr}	heater dissipation



Emissivity Determination



- Radiation Heat Loss

$$Q_{rad} = \sigma A_s \epsilon_{eff} (T_s^4 - T_\infty^4)$$

where

$$\epsilon_{eff} = \left[\frac{1}{\epsilon_s} + \frac{A_s}{A_\infty} \left(\frac{1}{\epsilon_\infty} - 1 \right) \right]^{-1}$$

for

$$A_s \ll A_\infty \quad \epsilon_{eff} = \epsilon_s$$

- σ = Stefan-Boltzmann constant
- A_s = area of the test sample
- A_∞ = area of the shroud
- ϵ_{eff} = effective emissivity
- ϵ_s = emissivity of test sample
- ϵ_∞ = emissivity of shroud
- T_s = sample temperature
- T_∞ = shroud temperature



Emissivity Determination



• Residual Helium Gas Heat Loss

$$Q_{gas} = \alpha_{eff} XYP_{\infty} A_s (T_s - T_{\infty})$$

where $\alpha_{eff} = \left[\frac{1}{\alpha_s} + \frac{A_s}{A_{\infty}} \left(\frac{1}{\alpha_{\infty}} - 1 \right) \right]^{-1}$

$$X = \frac{\gamma_{He} + 1}{\gamma_{He} - 1}$$

$$Y = \left(\frac{R_{He}}{8\pi T_{\infty}} \right)^{1/2}$$

for $A_s \ll A_{\infty}$ $\alpha_{eff} = \alpha_s$

- A_s = area of the test sample
- A_{∞} = area of the shroud
- α_{eff} = effective accommodation coefficient (ac)
- α_s = ac of He @ sample temperature
- α_{∞} = ac of He @ shroud temperature
- T_s = sample temperature
- T_{∞} = shroud temperature
- P_{∞} = pressure @ He shroud
- $g = C_p / C_v$
- C_p = specific heat @ constant pressure
- C_v = specific heat @ constant volume
- R_{He} = Helium gas constant

Ref: "Cryogenic Engineering", T.M. Flynn, p372 (7.9)



Emissivity Determination



• Lead Wire Heat Loss – Sensor Wires

– Assumptions

- Ohmic dissipation insignificant
- Wire radiation significant
- Long lead wires

$$Q_{wire} = \pi (0.1\sigma)^{\frac{1}{2}} \left(k_{wire}^{\frac{1}{2}} D_{wire}^{\frac{3}{2}} \epsilon_{wire}^{\frac{1}{2}} \right) T_s^{\frac{5}{2}}$$

- Q_{wire} = lead wire loss
- σ = Stephan-Boltzmann constant
- k_{wire} = Lead wire thermal conductivity (weighted average)
- D_{wire} = Lead wire outer diameter (includes insulation)
- ϵ_{wire} = lead wire insulation emittance
- T_s = sample temperature



Emissivity Determination



- **Lead Wire Heat Loss / Gain – Heater Wires**

- Assumption

- Ohmic dissipation significant (heater wires)
- Wire radiation insignificant

$$Q_{wire} = \left(\frac{\pi D^2 k}{4L} \right)_{wire} (T_s - T_\infty) + \left(\frac{2I^2 \rho L}{\pi D^2} \right)_{wire}$$

- Q_{wire} = heater lead wire loss/gain
- k_{wire} = Lead wire thermal conductivity (weighted average)
- D_{wire} = Lead wire outer diameter (includes insulation)
- L_{wire} = Lead wire length
- I_{wire} = Lead wire current
- ρ_{wire} = Lead wire electrical resistivity



Error Bar Determination



- All quantities in the aforementioned equations are known or measured except for the sample emissivity, ϵ_s . For either the steady-state or transient case, we can isolate this term and derive an expression in terms of the other variables.

$$\epsilon_s = f\left(A_s, A_\infty, A_{wx}, A_{ws}, L, T_s, T_\infty, \epsilon_w, \epsilon_\infty, \alpha_{He}, \alpha_\infty, P_\infty, Q_{heater}, m, C_p, \frac{dT}{dt}\right)$$

- The variance of ϵ_s is then given by

$$E_{\epsilon_s}^2 = \left(\frac{\partial \epsilon_s}{\partial A_s}\right)^2 E_{A_s}^2 + \left(\frac{\partial \epsilon_s}{\partial A_\infty}\right)^2 E_{A_\infty}^2 + \dots + \left(\frac{\partial \epsilon_s}{\partial Q_{heater}}\right)^2 E_{Q_{heater}}^2$$

Ref: "Physics Quick Reference Guide", American Inst. of Physics, p198




Error Bar Determination



Emissivity Error Contributions

$P_{\text{shroud}}=10^{-7}$ torr, $\text{Error}(P_{\text{shroud}})=20\%$







Error Bar Determination



Sample Emissivity, & Emissivity Error

$P_{\text{shroud}}=10^{-7}$ torr, $\text{Error}(P_{\text{shroud}})=20\%$







Cryochamber Operation




- **Baked-out cryochamber and emittance samples at 323K (50°C)**
- **Flooded Facility 225 chamber shroud with LN₂**
- **Pre-cooled cryochamber to 233K (-40°C) with GN₂ TCU**
- **Purged cryochamber with GHe**
- **Cooled cryochamber to 4.5 K with LHe**



Cryochamber Cool-Down



Cool-Down on 9/17/04






Cryochamber Temperature Profile



Cryochamber Average Temperature Versus Time





Cryochamber Test Results



- **All cryochamber test objectives were met**
 - Cooled-down from >300K to 4.5K in less than 6 hours
 - Thermal gradient < 0.5K
 - Thermal stability < 0.1K/hr
 - Chamber pressure < 5×10^{-8} Torr
- **Total cost of cryochamber was \$77,738 which included**
 - Design, fabrication and construction
 - Helium transfer lines
 - Instrumentation
 - Thermal blanketing
- **Helium consumption was as predicted – about 500 liters/day**



Test Sample Results



- **Emittance test samples**
 - M55J and Z306 sample results look good
 - Black Kapton delaminated from A1100 substrate
 - Steady state approach superior – less error than transient approach
- **Emittance data not released**
 - Parasitic losses and error bars being characterized
 - Emittance data to be published soon



Future Considerations and Improvements



- **Cryochamber**
 - Improve GN₂ TCU pre-cooling
 - Eliminate GHe purge during dewar changes
 - Plug inlet instead
 - Procure second helium transfer line
 - Improve time to change-out helium dewars
- **Test Samples**
 - Eliminate transient samples – pending analysis
 - Perform emittance testing of external radiator coating candidates:
 - Ball Infrared Black (BIRB)
 - Ball S13GLO
 - Black anodized aluminum



Questions?

